# RADIANT STRAIGHT INSTALLATION INSTRUCTIONS

#### WARNINGS

### PLEASE READ THE FOLLOWING INFORMATION BEFORE INSTALLING AND USING YOUR HEATED TOWEL RACK.

- These units should be installed by a certified electrician in accordance with the National Electrical Code (NEC) and the Canadian Electrical Code (CEC).
- The unit requires a 120 volt, 60Hz power source and should be installed on a GFCI protected circuit.
- Plug-in units should be connected to a grounded outlet with a minimum rating of 10 amps.
- Follow installation instructions to ensure unit is securely fixed to wall. Unit is designed for drying towels. Under no circumstances should anybody climb on or hang on unit.
- Unit is intended for indoor use only. Do not place units inside a shower, sauna, steam room, or wherever unit would be exposed to water.

#### CAUTION

- As this is a heating device, the surface temperature can increase depending on the ambient temperature in the room and the number of towels applied to the unit.
- Overloading the unit will cause the unit to become extremely hot and may result in a burn if touched and/or damage to towels.
- The fasteners provided with the installation kit are for convenience only and are not suitable for all installation conditions.
- It is the ultimate responsibility of the installer to ensure proper mounting hardware is employed in attaching the unit to the wall.

### OPERATING INSTRUCTION

- After installation, connect the electric power.
- Remove the protective cover from the switch and turn it to the on position.
- The indicator light will glow red and the towel warmer will start to heat Allow 10-20 minutes to heat up.
- This towel warmer has been designed to run continuously Turn off the switch or unplug the cord when the towel warmer is not in use for long periods of time.
- Never use an extension cord for Plug-in models.

#### CARE & MAINTENANCE


- Towels which contain soap or detergent residue may appear to have scorch marks; this is simply discoloration of the residue in the towels themselves.
- The unit is constructed from extremely durable 304 stainless steel. To maintain a good appearance, follow these simple instructions:

2x

#6-32 x 3/4 -in

- For routine cleaning, simply switch off the unit, allow to cool to room temperature, wipe with a damp cloth and buff with a soft, dry cloth.
- Under no circumstances should abrasive cleaners be used to clean the unit.

#### INCLUDED COMPONENTS



4 x



M6x10

G



**@** 







\* Included for hardwired **ELECTRICAL INFO** models only

150 1.3 120 watts amps volts

TOOLS REQUIRED

 $\bigcirc$ 


## WARRANTY

Two year limited warranty with proof of purchase will apply if all Terms and Conditions of Sale are met and Installation Instructions are adhered to.



FOR FULL WARRANTY VISIT: www.ambaproducts.com/warranty

# PLUG-IN MODELS



INTEGRATED SWITCH

- The Radiant Collection features an Integrated on/off switch.
- Remove plastic cover after installation.
- Switch is located on the bottom of the left vertical bar.
- Press switch to power on unit.
- Switch will illuminate when on.

#### AVAILABLE MODELS

RWH-SP RWP-SP

**RWH-SB RWP-SB** 

WH - wall mounted & hardwired

WP - wall mounted & plug-in

P-Polished B-Brushed

#### CONTACT

TEL:

404-3509738

FAX:

404-3550166

EMAIL:

customerservice@ambaproducts.com

www.ambaproducts.com



**REQUIRES** 


! CAUTION — SURFACE OF UNIT IS HOT WHEN ON!


# RADIANT STRAIGHT HARDWIRED


INSTALLATION INSTRUCTIONS




BEFORE STARTING ASSEMBLY MAKE SURE ALL COMPONENTS LISTED ARE IN THE PACKAGE











TURN UNIT ON WITH SWITCH